

## BUNK BED ASSEMBLY INSTRUCTIONS

- 1) Locate 4 x long vertical posts (the bolt holes that are the furthest from the ends are the bottom of the posts)
- 2) Locate the 4 x rails that hold the slats and put the corresponding numbers against the posts.
- 3) Bolt together.
- 4) One of the long rails that holds the slats will bolt to the two short vertical posts.
- 5) Locate the 90mm x 19mm pieces of timber that bolt across the head & end of the bed.
- 6) Bolt together.
- 7) On the ladder end there is one more upright that needs to bolt in place where the numbers match up.
- 8) From there you should find all the corresponding numbers on the pieces of timber to match up and complete the bed.

Please note – the longer bolts included go into the rails that hold the slats.